

Minor Scratches / Surface Marks



It is often the result of everyday maintenance, cleaning or rubbing. Normal wear and tear can create unsightly surface marks that diminish its shine and style.

- Grey in color, barely visibly
- Less than 50 microns/0.002 of an inch in depth.
- You cannot catch or feel under the fingernail.

Repair Method:

This type of damage can be repaired by polishing the surface using a rotary electric device such as corded drill or polisher with variable speed control. Recommended RPM: 1500-2000. Non-abrasive process - No sanding required.



DIY KIT

easy to use with electric drill
suitable for small areas.

PRO KIT

supplied with rotary polisher
suitable for small and large areas.